



June Tailor, Inc.

# Instructions for Iron-On Soft 'n Stretchy Ink Jet Transfer Sheets for Dark Fabrics

Soft 'n Stretchy Transfer Sheets for Dark Fabrics are an opaque white material to be used on dark or bright color fabrics. For optimal results, please read instructions carefully prior to use.

## 1. MATERIALS NEEDED

- Soft 'n Stretchy Transfer Sheets for Dark Fabrics (included in the package).
- Parchment Paper (included in the package).
- T-Shirt, garment or other project on which to apply the transfer. Works great with stretchy fabrics such as spandex, lycra, cotton, polyester and blends.
- Computer color ink jet printer.
- Ordinary household hand iron.
- Pillowcase.
- Smooth, hard, heat resistant surface, such as a wood cutting board for ironing. Do not use ironing board, glass or heat sensitive surfaces.

## 2. CREATE YOUR IMAGE

- Design your image on the computer using photos, graphics and/or text.
- DO NOT "mirror image". Use the standard printing orientation.
- You may wish to test your final image by printing to a plain piece of paper first.
- Insert a single transfer sheet into your printer so that printing appears on the unmarked, duller, rougher side of the sheet.
- Printer should be set at best quality, plain paper. Print image.
- Allow image to dry 30 minutes before transferring.
- Cut out image if desired. Note that the white of the transfer sheet will remain white after transferring.

## 3. IRON APPLICATION

- Preheat iron to highest (cotton) setting. DO NOT USE STEAM. (Empty any water that may be in iron. Allow iron to preheat for five minutes).
- Place a pillowcase on smooth, hard, heat resistant ironing surface such as a wood cutting board. Do not use ironing board. Iron pillowcase, if necessary, to remove wrinkles.
- Pre-iron garment or project to remove any moisture and wrinkles.
- Starting from an edge or corner of the transfer sheet, remove the backing paper and discard.
- Position transfer image side UP on project surface.
- Cover the entire image area with parchment paper (included in the package). If parchment is damaged or misplaced, baking parchment (available at grocery stores) may be substituted.
- Using firm pressure, slowly iron over the entire surface with sufficient overlapping (1) side-to-side (2) bottom to top and (3) along the edge moving continuously for 2-3 minutes.
- Remove parchment paper immediately or when it cools.
- Depending upon the material used, a gentle pulling / stretching motion applied to the fabric after removal of the backing sheet may aid in the process of the transfer setting into the fibers.

## 4. LAUNDERING INSTRUCTIONS

- Wash and dry according to your fabric's normal washing instructions.
- After washing, transfer may be directly ironed on.

## 5. STORAGE

- Always store unused product in original package in a flat, cool, dry place.

This product is intended for use in standard ink jet printers only. Do not use in other printers or copiers such as laser printers or any other printer / copier that applies heat, as it may damage the machine. Test the product you plan to use to determine the suitability of the product for your equipment, methods and substrate material.