



June Tailor, Inc.

## Dark T-Shirt Transfer Sheet Instructions

Dark T-Shirt Transfer Sheets are solid white transfer sheets for use in your color ink jet printer. Note that whatever is white on your transfer will remain white on your t-shirt or project. Dark T-Shirt Transfers have multiple blue lines printed on the back side of the sheet.

Read instructions carefully prior to use.

### MATERIALS NEEDED:

- T-shirt, garment or other project on which to apply transfer.
- Computer and color ink jet printer.
- Ordinary household hand iron.
- Pillowcase.
- Smooth, hard, heat resistant surface such as a wood cutting board for ironing. Do not use ironing board, glass or heat sensitive surfaces.

### CREATE YOUR IMAGE:

- Design your image on the computer using your own photos, graphics and / or text. Do NOT reverse or mirror image.
- Test print your image on a plain piece of paper.
- Insert a single Dark T-Shirt Transfer Sheet into your printer so that printing occurs on the plain, unmarked side of the transfer sheet.
- Set printer at normal quality, plain paper. Print image.
- Allow image to dry 30 minutes before transferring.
- To keep printed image edges from tearing, gently separate the front transfer from the paper backing just past printed image, then replace layers.
- Using a scissors or craft knife, trim out image to desired shape.
- **Peel finished transfer image from backing paper.**

### IRON APPLICATION:

- Pre-heat iron to high (cotton) setting. DO NOT USE STEAM. (Empty any water that may be in iron. Allow iron to preheat for five minutes).
- Place pillowcase on smooth, hard, heat resistant ironing surface such as a wood cutting board. Do not use ironing board. Iron pillowcase to remove wrinkles.
- Iron project to remove any moisture and wrinkles.
- Position Dark T-Shirt Transfer image FACE UP on project surface. Cover COMPLETELY with parchment paper provided. NOTE: Parchment paper can be used for multiple transfer applications.
- Using pressure, SLOWLY iron over the entire transfer in side-to-side and top-to-bottom motions, making sure that each area of the transfer, especially edges, receives 20 seconds of heat. A half sheet will take 45 to 60 seconds to transfer. A full sheet will take 90 to 120 seconds to transfer.
- Remove parchment paper when cool.
- If applying multiple images to a single project, it is recommended that you leave the parchment paper in place until all images are ironed on so that the heat of other ironing applications does not affect already fused images.

- Check to make sure transfer, and all edges and corners are thoroughly fused. Replace parchment and iron if additional time is needed.

NOTE: Additional time may be needed for 100% cotton fabrics, larger transfers or cooler irons, as iron temperatures can vary greatly. The dye in some colored fabrics may bleed through white areas of transfers. Check transfer frequently when ironing.

### LAUNDERING INSTRUCTIONS

- Wait 24 hours before washing.
- Turn garment inside out.
- Machine wash in cold water with mild detergent, NO BLEACH. Do not use hot water.
- Remove promptly from washer as bleeding may occur if left wet. If bleeding occurs, rewash.
- Tumble dry low or lay flat to dry. If air drying, blot excess water from image with a clean dry towel.
- Do not iron directly on transfer. If ironing is necessary, cover with parchment provided or baking parchment (available at grocery stores).

### STORAGE

- Always store unused product in original package in a flat, cool, dry location.

This product is intended for use in standard ink jet printers only. Do not use in other printers or copiers such as laser printers or any other printer/copier that applies heat, as it may damage the machine. Test the product you plan to use to determine the suitability of the product for your equipment, methods and substrate material.