



Dark T-Shirt Iron-On Ink Jet Transfer Instructions

Dark T-Shirt Transfer sheets are opaque white sheets for use in your color ink jet printer.

For optimal results, please read instructions carefully prior to use.

1. MATERIALS NEEDED

- Dark T-Shirt Transfer sheets and parchment paper (included in the package).
- T-shirt, garment or other project on which to apply transfer material.
- Computer color ink jet printer.
- Ordinary household hand iron.
- Pillowcase.
- Smooth, hard, heat resistant surface, such as a wood cutting board for ironing. Do not use ironing board, glass or heat sensitive surfaces.

2. CREATE YOUR IMAGE

- Design your image on the computer using graphics, text or photos. Do NOT reverse or mirror image.
- If so desired, test print your image on a plain piece of paper.
- Insert a single sheet of Dark T-Shirt Transfer paper into your printer so that printing occurs on the plain, unmarked side of the transfer sheet.
- Printer should be set at normal quality, plain paper. Print image.
- Allow image to dry 30 minutes before transferring.
- To keep printed image edges from tearing, gently separate the front sheet from the backing paper just past printed image, then replace layers.
- Using a scissors or craft knife, trim out image to desired shape.
- Gently peel finished Dark T-Shirt Transfer image from backing paper.

3. PREPARE TO IRON

- Place pillowcase on smooth, hard, heat resistant ironing surface such as a wood cutting board. Do not use ironing board. Iron pillowcase, if necessary, to remove wrinkles.
 - Pre-iron project to remove any moisture and wrinkles.
 - Position Dark T-Shirt Transfer image FACE UP on project surface. Cover COMPLETELY with parchment paper provided.
- NOTE: Parchment paper can be used for multiple transfer applications.

4. FOR 100% COTTON FABRIC

- Preheat iron to highest (cotton) setting. DO NOT USE STEAM. (Empty any water that may be in iron. Allow iron to preheat for five minutes).
- First, using FIRM PRESSURE, holding the iron with both hands and applying your body weight, iron on each area of the sheet for 20 seconds, making sure to lift the iron completely off the surface when moving to a new position. Be sure to iron all corners and edges of the sheet.
- Then using FIRM PRESSURE, iron over the entire image using consistent up/down and side-to-side motion for an additional 1-1/2 minutes, making sure to iron all corners and edges.
- Allow the parchment paper to cool for one to two minutes. Gently peel off parchment paper.
- If applying multiple images to a single project, it is recommended that you leave the parchment paper in place until all images are ironed on so that the heat of other ironing applications does not affect already fused images.

5. FOR 50/50 COTTON/POLYESTER BLEND FABRIC

- Preheat iron to medium, medium/high (wool) setting. DO NOT USE STEAM. (Empty any water that may be in iron. Allow iron to preheat for five minutes).
- First, using moderate pressure, iron over the entire image using consistent up and down motions for 30 seconds making sure to cover all corners and edges.
- Then using moderate pressure, iron over the entire image using consistent side-to-side motions for 30 seconds, making sure to iron all corners and edges.
- Repeat the previous two steps.
- Iron over entire surface in a circular motion for an additional minute. (Three minutes total pressing time).
- Allow the parchment paper to cool for one to two minutes. Gently peel off parchment paper.
- If applying multiple images to a single project, it is recommended that you leave the parchment paper in place until all images are ironed on so that the heat of other ironing applications does not affect already fused images.

6. WASHING INSTRUCTIONS

- Turn garment inside out.
- Machine wash cold water with mild detergent, NO BLEACH. Do not use hot water.
- Remove promptly from washer as bleeding may occur if left wet. If bleeding occurs, rewash.
- Tumble dry low or lay flat to dry. If air drying, blot excess water from image with a clean dry towel.
- Do not stretch the image as cracking may occur.
- Do not iron directly on transfer. Cover with parchment provided or baking parchment (available at your grocery store) and allow to cool before removing.

7. STORAGE

- Always store unused product in original package in a flat, cool, dry place.

This product is intended for use in standard ink jet printers only. Do not use in other printers or copiers such as laser printers or any other printer/copier that applies heat, as it may damage the machine. Test the product you plan to use to determine the suitability of the product for your equipment, methods and substrate material.